
PACCAR Power Take-Off (PTO)

© 2025 PACCAR Inc. - All Rights Reserved

This manual illustrates and describes the operation of features or equipment which may be either standard or optional on this vehicle. This manual may also include a description of features and equipment which are no longer available or were not ordered on this vehicle. Please disregard any illustrations or descriptions relating to features or equipment which are not on this vehicle. PACCAR reserves the right to discontinue, change specifications, or change the design of its vehicles at any time without notice and without incurring any obligation. The information contained in this manual is proprietary to PACCAR. Reproduction, in whole or in part, by any means is strictly prohibited without prior written authorization from PACCAR Inc.

Chapter 1 | Safety

Safety Messages and Notes 6



NOTE

Pumping the accelerator pedal will not assist in starting the engine.

Chapter 2 | General Information

Introduction and Disclaimers 10

Reference Sources 11

Chapter 3 | Specifications

Electrical Connectors and Terminal Details 14

